AngelSense

Keep Your Loved One Safe





01The Kit Content



1 AngelSense GPS inside protective sleeve



2 Three fasteners to attach the sleeve to garment



3 Magnetic key to open the fasteners




4 USB charging cable

02Device Buttons & Light Indicators

GPS SIGNAL



When operating properly both lights remain off If you'd like to verify the device is on, press the power button and both lights will appear



04Installing The App





or open app.angelsense.com from any browser





Download the "AngelSense Guardian" App that includes a complete user guide

05Opening Fasteners

1 Bring the magnetic key close to the cap and let it snap. Push the key down onto the cap





2 Pull the key up to detach the cap from the pin

Watch videos

06Securing Device To Garment

1 Insert the device into the pocket

2 Put the fastener pin through the material of the garment and the sleeve, and secure using the fastener cap




Watch videos

07Wearing Options



There are many creative ways to wear the device



08Additional Wearing Options (Sold Separately)



Additional non-removable wearing accessories can be purchased in the <u>AngelSense Store</u> under My Account in the app

We Are Special Needs Parents Too!

Our Customer Care Team Members are all parents of children with special needs, and we all use AngelSense daily with our own children. We will be happy to share our own experience with you.

Call Us, We Understand!





support@angelsense.com (1-646-770-2950





www.angelsense.com/help